


SLP



The SLP slanted slit plate is used along with the bolt, nut and KS clamping washer to fasten the JVAeco+ brickwork support bracket to the anchor channel. When using a suitable dowel, the slanted slit plate SLP is used along with the KS clamping washer to attach it to the shell. The JVAeco+ can be adjusted vertically by ± 30 mm and perfectly aligned using the teeth in the bracket head and a slanted slit plate. The slanted slit plate can be used variably depending on the desired load level.

Artikel	Typ	H	B	L	W
SLP	Wedge adjuster DX	9 mm	65 mm	85 mm	0.076 kg

