PohlCon

PARTNER
FROM START
TO FUTURE.

Counter Trough GW for Cable Clamps H / AC

Assembly instructions



Cable Clamp – Type H



Fitting an H-type cable clamp, using a B7 rail as an example



Fit the H-clamp to the lower and upper edges of the rail profile, including the cable. The head of the H-clamp should be facing upwards.



Insert the counter trough from above, along the back of the cable. The counter trough rests on the clamp walls with its small tabs and cannot slip out of place.



Screw the clamp, together with the cable and counter trough, onto the profile. Take care not to damage the cable sheath whilst tightening the screws.

Cable Clamp – Type AC



Fitting an AC cable clamp, using a KHA 8 profile as an example



Attach the AC clamp, including the cable, to the upper edge of the KHA 8 profile.



Insert the counter trough from above, along the back of the cable. Its tabs rest on the clamp walls, preventing it from slipping.



Screw the clamp, together with the cable and counter trough, to the upper edge of the profile. Take care not to damage the cable sheath whilst doing so.

All rights reserved. This document may not be reprinted or electronically reproduced without our prior written permission. The contents are subject to change without notice. Errors and omissions excepted. The publisher accepts no liability whatsoever on any legal grounds. This document supersedes all previous documentation.

© PohlCon | PC-LIT-MA-GW-EN | 05-2020 | 3. v. | 10-2026

PohlCon GmbH
Nobelstr. 51
12057 Berlin
Germany

T +49 30 68283-04

www.pohlcon.com