



# Brush installation units made of plastic, round

Assembly instruction






Round installation unit with a brush cable outlet, external diameter of  $305 \, \text{mm}$ , for installation of up to three device containers. For floor cover depths of  $10, 8, 5, \text{ and } 3 \, \text{mm}$ . Lock-in leads of  $50 \, \text{or } 80 \, \text{mm}$  needed for complementation.




**Screed floors** 

In case of a screed-covered system, remove shuttering tube and insert installation unit directly into the installation opening.



Hollow floors and raised floors

For hollow or raised floors insert installation unit directly into the installation opening.



Hinged cover mechanism

Open cover completely, press lug down with a screwdriver while moving the hinge to the left at the same time.




Hinged cover removal

Press hinge together using pliers until the lugs snap out of the frame. Remove cover towards the front.



Fastening the installation frame

Insert frame into installation opening from the top and tighten the preassembled claws with a crosshead screw. Check to ensure that the frame fits tightly.




Claws

Custom madel applications require the use of claw UDKS 40-80. If that is the case, the pre-assembled claws are removed and replaced. Turn claw body so that the frame can be inserted from the top.



#### The use of claws

The claws UDKS 40-80 stretch under the raised floor panel, into the screed or into the cover plate of the floor box.




### The mounting of lock-in leads

The separately delivered lock-in leads can be inserted into the installation unit from the top and tightly screwed. For a flat installation the 50 mm lock-in lead must be used.




#### Inserting the device cup

Latch the device cup as deeply into the lock-in lead as possible.




## Lock-in leads

Depending on the installation situation, lock-in leads of heigths either 50 mm and 80 mm can be chosen. Device cups can be gradually lowered by up to 30 mm.




# Releasing the device cup

Insert screwdriver or mounting lever between frame and device cup. Release lugs on the side individually and remove device cup.




## Floor cover in hinge cover

After replacing the hinge cover, leave cover open in locking position. Cut floor cover to no more than 10 mm from its precise fit and glue onto the steel reinforcement. Optionally, cover inlays are available of 2, 5 or 6 mm thickness.




# Opening lever

Operate self-locking opening lever behind the cable outlet.




# Cable connection flap

Pan cable connection flap by 180° and latch it in.




#### Brush cable outlet

Leadi out cables through the open brush cable outlet.



#### Minimum installation height

Minimum installation height: 89 mm when using a 50 mm lock-in lead, respectively 109 mm when using a 80 mm lock-in lead, and in connection with coupler plugs up to H = 35 mm.



#### Maximum installation height

Maximum installation height: 109 mm when using a 50 mm lock-in lead, respectively 134 mm when using a 80 mm lock-in lead.




#### The use of UG45

The device cup UG45-4 is suitable for using installation devices measuring  $45 \times 45$  mm or  $45 \times 22,5$  mm. Minimum installation height: 82 mm when using the 50 mm lock-in lead, respectively 102 mm when using the 80 mm lock-in lead and in connection with coupler plugs up to H = 35 mm.




## The use of UG3

To achieve an even flatter installation depth, use our newly developed device cup UG3. Minimum installation height: 82 mm when using a 50 mm lock-in lead, respectively 102 mm when using an 80 mm lock-in lead and in connection with coupler plugs up to H = 35 mm.



## **Device insert**

Place device into the installation unit from the top and tighten to the frame using four threaded screws. Minimum installation depth: 63 mm. Suitable for maximum two double sockets and up to six data modules. Install installation technology using boards.



#### Data device carrier

Up to nine data modules can be installed in the data device carrier using boards in the installation unit. Minimum installation height: 96 mm when using a 50 mm lock-in lead, respectively 116 mm when using an 80 mm lock-in lead set. Use the lock-in lead considering the bending radius.

	_																	1				
																						-
																			-			-
																						-
												_										
												-				-				_		-
	_											_	_							_		
	-																			-		-
	-												-	_	_	-						
	+											_				+				$\dashv$		
																				-		_
																						-
	+													-					_			
	-												_	_	_	-			_			
	+						-					-	-	-	-	+	-		-	-		
																			$\dashv$			
	-						_					-	-	-	_	-	-		-	-		
																			T			
	+											+		-		+			$\dashv$	+		
												-							-	-		
																					$\Box$	
$\vdash$	+													-		+						
																				_		
	-											-	-			-			-	-		
		1																				

All rights reserved. Reprinting and any electronic reproduction only authorised with our written permission. Errors excepted and subject to technical changes. No liability can be accepted by the publisher on any legal basis whatsoever. This publication supersedes all previous versions of the document, thereby rendering them invalid.

© PohlCon | PC-LIT-MA-UFS-UEK3-R-EN | 12-2013 | 5. v. | 06-2024

# PohlCon GmbH

Nobelstr. 51 12057 Berlin Germany

T +49 30 68283-04 F +49 30 68283-383

www.pohlcon.com